



26 Blanchard Street | Newark NJ 07105 | (973) 589-7800 | www.prisco.com

# PRISCO® 3451 Fountain Concentrate

## **Product Description:**

PRISCO 3451 Fountain Solution Concentrate is designed for use on sheetfed presses. PRISCO 3451 may be used as a one-step solution on conventionally dampened press. The product may be combined with alcohol or with an Alkaless alcohol substitute to reduce or eliminate alcohol on continuously dampened presses.

## Advantages:

- Prevents plate blinding and picture framing
- Buffered for use in low and medium alkalinity water
- Contains no phosphates
- · Effectively eliminates fungus growth

### **Directions:**

Use 2 to 4 ounces (1.5-3%) of PRISCO 3451 in each gallon of water. The pH will be approximately 4.0-4.5. Once optimum level has been determined, measure conductivity for use as a reference when preparing fresh batches of press-ready fountain solution.

Product Code: READ SDS BEFORE USING THIS PRODUCT

H647

### Packaging:

5-Gallon cube, 30-Gallon drum, 55-Gallon drum (use plastic pumps with drums) and 275-Gallon tote.

1703

**Atlanta Support:** 678-601-4140 **Orders:** 800-241-6049

Newark
Support: 973-589-7800
Orders: 800-222-0146

**Boston** 781-749-4590 800-222-0146

**Philadelphia** 856-662-3373 800-222-0146

**Chicago** 630-543-4600 800-241-6049

**Belgium** 32 (0) 56 40 41 82 32 (0) 56 40 41 83 **Dallas** 817-477-4770 800-241-6049

**United Kingdom** 44 (0) 1423 810 320 **Los Angeles** 909-923-1879 800-825-4846

**Toronto** 905-953-9393 888-460-4406

**Miami** 954-971-0436 800-241-6049

**Australia** 61 2 4702 1211