

PRISCO[®] **EEZY-KLENE** AND EEZY-SCRUB



Product Description: PRISCO EEZY-KLENE is a creamy-white emulsion that acts as a rubber deglazer, cleaner and conditioner. It contains plasticizers that help prevent premature hardening of rollers and blankets, while providing deep cleaning action during wash-ups and color changes. **PRISCO EEZY-SCRUB** performs the same function, but contains a mild abrasive for more powerful cleaning.

Advantages:

- Low VOC level: 0.68 lb/gal (81.2 g/l)
- Flashpoint >212° F (>100° C)
- Thorough and deep cleaning of ink rollers
- Improves ink receptivity of ink rollers
- Compatible with EPDM rollers when used as directed

Directions: After cleaning ink off the rollers, apply PRISCO EEZY-KLENE or PRISCO **EEZY-SCRUB** along the top of the rollers. Allow the product to run-in for 5 to 6 minutes. Apply roller wash, then set blade and rinse with roller wash. The product should always be removed from the rollers within 1-hour of application. For best results, use a high quality wash that is compatible with with the roller compound you are cleaning. Consult your Prisco represenative for specific recomendations.

Product Codes: C551 EEZY-KLENE C552 EEZY-SCRUB

READ MSDS BEFORE USING THIS PRODUCT

Packaging: 16 oz. (473ml) bottles

01/11

ATLANTA PRINTERS' SERVICE 800-241-6049 26 Blanchard Street

Newark, New Jersey 07105 (212) 962-6565 • (973) 589-7800 FAX (973) 589-3225 BOSTON 781-749-4590 www.prisco.com FAX: 781-740-2866

678-602-4140

FAX: 678-602-4139

800-654-1357 630-543-4600 FAX: 630-543-0856

CHICAGO

LOS ANGELES 800-825-4846 909-923-1879 FAX: 909-923-4079 NEW YORK/NEWARK 973-589-7800 212-962-6565 FAX: 973-589-3225

PHILADELPHIA 800-222-0146 856-662-3373 215-462-3636

FAX: 856-486-4552

PRISCO CANADA TORONTO 888-460-4406 905-953-9393 FAX: 905-953-1331

PRISCO EUROPE (U.K.) +44 1423 810 320 FAX: +44 1423 810 319 PRISCO EUROPE (Continent) +32 56 40 41 82 +32 56 40 41 83

DALLAS

800-338-2241 817-477-4770 FAX: 817-473-4515 MIAMI 800-432-5068 954-971-0436 FAX: 954-971-9218