Prisco[®] E-Cure DI 605 UV Digital Gloss Coating

UV Coating Technical Data Sheet





The Prisco E-Cure DI 605 is a high gloss UV coating for offline application over digital media. It is designed to produce an even and fast curing film formation with a superior gloss finish. This allows for quick turnaround times and an even defect-free surface. This product is designed to have excellent flexibility, adhesion properties, and gloss depth and clarity. The E-Cure 605 has improved adhesion and leveling over the tougher based toners. This product has had success over Konica Minolta, Xeikon, and HP Indigo 10000 digitally printed materials.

Advantages:

- Good gloss levels
- Good Cure Response
- Good Rub and Taber Resistance
- Non-Yellowing
- Low VOC

Physical Properties:

Viscosity

Gloss Wt./gal Cure

MEK Rubs

Application:

Sheetfed Flexo

- Application Viscosity-Stir and use as received.
 - Recommended Application Temperature 70-80°F
- Equipment-Blanket and tower coaters, anilox coaters
- Curing-Sufficient amount of focused UV energy depending on press, press speed, and dryer capability
- Inks-Digital Toners
- Clean up-Prisco UV Cleaner
- Shelf Life-6 months stored at room temperature.

Product Code: RI01-55A (55 gallon drum), RI01-30A (30 gallon drum), RI01-5GB (5 gallon pail), RI01-1GF (1 Gallon Pail)

Prisco recommends that you test coatings for specialty applications using the actual raw materials to be used in production prior to printing.

Read MSDS before using this product

an ISO 9001:2008 Registered Facility

PRINTERS' SERVICE

26 Blanchard Street Newark, New Jersey 07105 (212) 962-6565 • (973) 589-7800 FAX (973) 589-3225 www.prisco.com **ATLANTA** 800-241-6049 404-876-1234 FAX: 404-873-2917

BOSTON

781-749-4590

FAX: 781-740-2866

CHICAGO 800-654-1357 630-543-4600 FAX: 630-543-0856

DALLAS

800-338-2241

817-477-4770

FAX: 817-473-4515

LOS ANGELES 800-825-4846 909-923-1879 FAX: 909-923-4079

MIAMI

800-432-5068

954-385-1975

FAX: 954-385-8875

NEW YORK/NEWARK 973-589-7800 212-962-6565 FAX: 973-589-3225

PHILADELPHIA 800-222-0146 856-662-3373 215-462-3636

FAX: 856-486-4552

PRISCO CANADA TORONTO 888-460-4406 905-953-9393 FAX: 905-953-1331

PRISCO EUROPE (U.K.) 44(0)1423 810 320 FAX: 44(0)1423 810 319 PRISCO EUROPE (Continent) 32(0)56 42 35 76 32(0)56 42 35 97

18-22 seconds, #3 EZ Zahn timed @ 25°C/77°F 110-150 cps, Brookfield LV Viscometer @ 25°C/77°F >90 9.3 lbs/gal 100 fpm, 200 wpi American UV Mini Conveyor* *Note-tested in controlled lab conditions 15-20 Double Rubs