



Product Bulletin

PRISCO® Salt Deglazer



Product Description: Prisco Salt Deglazer removes calcium carbonate as well as other salt build-ups. **SALT DEGLAZER** also keeps rollers cleaner, prevents roller stripping and promotes more consistent color.

Directions: Wash rollers as usual. When rollers are clean and dry, disengage wash-up blade and apply **Prisco Salt Deglazer** liberally across rollers. Let **Prisco Salt Deglazer** run in for 2 to 4 minutes, then engage wash-up blade. Apply additional rinse, let sit for 1 to 2 minutes, then dry off with an application of water and presswash. If severe roller contamination exists, removal of rollers may be required for hand cleaning.

Product Code: C620

READ MSDS BEFORE USING THIS PRODUCT

Packaging: quarts

1 gallon plastic

55 gallon plastic drum

11/12

PRINTERS' SERVICE
26 Blanchard Street
Newark, New Jersey 07105
(212) 962-6565 • (973) 589-7800
FAX (973) 589-3225
www.prisco.com

ATLANTA
800-241-6049
678-602-4140
FAX: 678-602-4139

BOSTON
781-749-4590
FAX: 781-740-2866

CHICAGO
800-654-1357
630-543-4600
FAX: 630-543-0856

DALLAS
800-338-2241
817-477-4770
FAX: 817-473-4515

LOS ANGELES
800-825-4846
909-923-1879
FAX: 909-923-4079

MIAMI
800-432-5068
954-971-0436
FAX: 954-971-9218

NEW YORK/NEWARK
973-589-7800
212-962-6565
FAX: 973-589-3225

PHILADELPHIA
800-222-0146
856-662-3373
215-462-3636
FAX: 856-486-4552

PRISCO CANADA
TORONTO
888-460-4406
905-953-9393
FAX: 905-953-1331

PRISCO EUROPE (U.K.)
+44 1423 810 320
FAX: +44 1423 810 319
PRISCO EUROPE (Continent)
+32 56 40 41 82
+32 56 40 41 83