



## QUESTAR

### UNIVERSAL PLATE CLEANER

**Product Description:** Questar Universal Plate Cleaner is a revolutionary emulsion containing cleansers and desensitizers. It will not harm the image area of baked or un-baked CTP plates, no-process CTP printing plates. Questar Universal Plate Cleaner will rapidly and thoroughly clean ink from both image and non-image areas of the plate. The desensitizing action of Questar Universal Plate Cleaner eliminates scumming, tinting, toning, plugging, and scratching, thus preventing minor plate problems from causing excess waste and downtime while the job is on press. Plates may be stored directly after use of Questar Universal Plate Cleaner.

**Advantages:**

- Contains active plate preservers for storage
- Desensitizes scratched areas and extends the life of the plate on press
- Suitable for no-process CTP plates, CTP plates and unbaked positive plates

**Directions:**

- Routine Cleaning: Shake the container well. Apply Questar Universal Plate Cleaner to the plate using a damp sponge until the ink is completely removed from the entire plate. Wipe off excess with the back of the sponge.
- Scratch Removal: Shake the container well. Apply Questar Universal Plate Cleaner with a soft dry pad or cloth. Rub the scratch firmly in the direction of the scratch until the ink is removed. Wipe the area with a sponge dampened with fountain solution.
- Storage: Shake the container well. Apply Questar Universal Plate Cleaner with a damp sponge and buff dry with dry wiper or cheesecloth.

**Product Code:** HF53

**READ MSDS BEFORE USING OR STORING THIS PRODUCT**

**Packaging:** 1-Quarts (0.946 Liter), 1-Case of 12 quarts (11.355 Liter)

0521

<b>Atlanta</b> Support: 678-601-4140 Orders: 800-241-6049	<b>Boston</b> 781-749-4590 800-222-0146	<b>Chicago</b> 630-543-4600 800-241-6049	<b>Dallas</b> 817-477-4770 800-241-6049	<b>Los Angeles</b> 909-923-1879 800-825-4846	<b>Miami</b> 954-971-0436 800-241-6049
<b>Newark</b> Support: 973-589-7800 Orders: 800-222-0146	<b>Philadelphia</b> 856-662-3373 800-222-0146	<b>Belgium</b> +32 56 40 41 82	<b>United Kingdom</b> +32 56 40 41 82	<b>Toronto</b> 905-953-9393 888-460-4406	<b>Australia</b> 61 2 4702 1211